



Using JTAG with SystemC

Implementation of a Cycle Accurate Interface

Jeremy Bennett
Embecosm

Application Note 5. Issue 1
Published January 2009



Legal Notice

This work is licensed under the Creative Commons Attribution 2.0 UK: England & Wales License. To view a copy of this license, visit <http://creativecommons.org/licenses/by/2.0/uk/> or send a letter to Creative Commons, 171 Second Street, Suite 300, San Francisco, California, 94105, USA.

This license means you are free:

- to copy, distribute, display, and perform the work
- to make derivative works

under the following conditions:

- *Attribution.* You must give the original author, Jeremy Bennett of Embecosm (www.embecosm.com), credit;
- For any reuse or distribution, you must make clear to others the license terms of this work;
- Any of these conditions can be waived if you get permission from the copyright holder, Embecosm; and
- Nothing in this license impairs or restricts the author's moral rights.

The software for the SystemC cycle accurate JTAG interface written by Embecosm and used in this document is licensed under the GNU General Public License (GNU General Public License). For detailed licensing information see the file **COPYING** in the source code.

Embecosm is the business name of Embecosm Limited, a private limited company registered in England and Wales. Registration number 6577021.



Table of Contents

1. Introduction	1
1.1. Rationale	1
1.2. Target Audience	1
1.3. Further Sources of Information	1
1.3.1. Written Documentation	1
1.3.2. Other Information Channels	1
1.4. About Embecosm	2
2. Overview of Technologies	3
2.1. JTAG (IEEE 1149.1)	3
2.1.1. Boundary Scan	3
2.1.2. JTAG Chip Architecture	5
2.2. OSCI SystemC IEEE 1666	8
3. Cycle Accurate SystemC JTAG Interface	10
3.1. Abstract Representation of the JTAG Interface	10
3.2. Application Programming Interface (API)	10
3.2.1. TAP Action Classes	10
3.2.2. The JtagSC SystemC Module Class	12
3.2.3. Using the Interface	14
3.3. Installation	14
3.4. Implementation Detail	14
3.4.1. JtagSC	15
3.4.2. TapAction	16
3.4.3. TapActionReset	16
3.4.4. TapActionIRScan	17
3.4.5. TapActionDRScan	18
3.4.6. TapStateMachine	21
4. Examples	23
4.1. JTAG Reset	23
4.2. Writing the Instruction Register	24
4.3. Writing a 12-bit JTAG Data Register	25
4.4. Reading a 73-bit JTAG Data Register	27
5. Summary	29
Glossary	30
References	32

List of Figures

2.1. Boundary scan example: two chips	3
2.2. Boundary scan example: chip interconnections	3
2.3. Boundary scan example: scan cells on inputs and outputs	4
2.4. Boundary scan example: scan cells connected	4
2.5. Boundary scan example: shift register	4
2.6. JTAG minimal architecture	5
2.7. TAP state machine	6
2.8. JTAG architecture with optional reset port and ID register	7
2.9. JTAG architecture with user registers	8
3.1. Class diagram for JtagAction and subclasses	10
3.2. State machine for the JtagActionIRScan process.	18
3.3. State machine for the JtagActionDRScan process.	20
4.1. Module structure for the ORPSoC JTAG example	23
4.2. VCD trace of a JTAG reset request	24
4.3. VCD trace of a JTAG instruction register write request	25
4.4. VCD trace of a "small" JTAG data register write request	26
4.5. VCD trace of a "large" JTAG data register read request	27

Chapter 1. Introduction

This document describes a cycle accurate SystemC interface for JTAG (IEEE 1149.1).

This interface simplifies a number of common practical problems:

- Interfacing to cycle accurate SystemC models created from RTL using tools such as Verilator, ARC VTOC or Carbon Design Systems SpeedCompiler.
- Interfacing to traditional event driven simulators, such as Cadence NC, Synopsys VCS and Mentor Graphics ModelSim using SystemC co-simulation.
- Implementing SystemC test benches which drive physical hardware via JTAG
- Interfacing to external tools such as debuggers. For example to develop versions of *GDB* which can work through JTAG ports.

1.1. Rationale

Directly interfacing to the JTAG cycle accurate ports of a SystemC model is a complex task, requiring careful modeling of the JTAG Test Access Port (TAP) state machine.

More abstractly JTAG is an interface allowing reading and writing of hardware registers.

The interface described in this application note provides this abstraction. The user queues registers to be read or written, and the interface ensures the correct bit sequences are driven on the JTAG pins. The interface is implemented as SystemC module with a FIFO on which the user queues requests and signal ports to which the low level JTAG ports are connected.

A reference implementation is provided [2]. This application note gives a number of examples of the interface in use (see Chapter 4).

1.2. Target Audience

If you need to interface SystemC to a cycle accurate or pin level model of a JTAG port, this interface and application note is for you. If at the end of your endeavors you are better informed, please help by adding to this document.

1.3. Further Sources of Information

1.3.1. Written Documentation

JTAG and SystemC are both IEEE standards (1149.1 and 1666 respectively), and the standardization documents are the ultimate reference. The SystemC standard [5] is a free PDF download (a novelty for the IEEE), but the JTAG standard [3] costs money. The Texas Instruments JTAG primer [4] is a useful free alternative.

The files making up the reference implementation for the JTAG SystemC interface are comprehensively commented, and can be processed with Doxygen [1]. Each class, member and methods behavior, parameters and any return value is described.

1.3.2. Other Information Channels

There is a wealth of material to support both SystemC and JTAG on the Internet.

The Open SystemC Initiative (OSCI) provide an open source reference implementation of the SystemC library, which includes tutorial material in its documentation directory. These may be accessed from the OSCI website (www.systemc.org).



OSCI also provide a number of public mailing lists. The help forum and the community forum are of particular relevance. Subscription is through the OSCI website (see above).

1.4. About Embecosm

Embecosm is a consultancy specializing in open source tools, models and training for the embedded software community. All Embecosm products are freely available under open source licenses.

Embecosm offers a range of commercial services:

- Customization of open source tools and software, including porting to new architectures.
- Support, tutorials and training for open source tools and software.
- Custom software development for the embedded market, including bespoke software models of hardware.
- Independent evaluation of software tools.

For further information, visit the Embecosm website at www.embecosm.com.

Chapter 2. Overview of Technologies

2.1. JTAG (IEEE 1149.1)

This section provides an introduction to IEEE 1149.1 [3] developed by the Joint Test Action Group (JTAG).

JTAG was developed as interface to support boundary scan testing. However the resulting interface has proved more generally useful as a way to get data into and out of registers in hardware.

2.1.1. Boundary Scan

Boundary scan testing is a way of testing that the inputs and outputs of components on a board, or sub-systems on a chip, are connected correctly.

Figure 2.1 shows a board with two chips, A and B, each with three inputs (numbered 1 to 3) and three outputs (numbered 4 to 6).




Figure 2.1. Boundary scan example: two chips

These chips are interconnected as shown in Figure 2.2. Output pins 5 and 6 of chip A are connected to the input pins 1 and 3 of chip B respectively. Output pins 4 and 6 of chip B are connected to input pins 1 and 2 of chip A respectively. The other pins are not connected.




Figure 2.2. Boundary scan example: chip interconnections

The objective of boundary scanning is to determine that the inputs and outputs which should be connected, are connected, and that those which should not be connected are not connected.

Boundary scan adds a simple logic cell (a *scan cell*) to each input and output, which can record the current state of that input or output as shown in Figure 2.3.




Figure 2.3. Boundary scan example: scan cells on inputs and outputs

Normally the cell has no impact on the input or output. However the cells may be directed to *capture* the current state of the input or output. For inputs, the signal about to leave the chip is captured in the cell. For outputs, the signal about to enter the chip is captured in the cell.

The cells may also be directed to *update* their associated input or output. For inputs the stored value is injected onto the external connection. For outputs the stored value is injected into the chip.



Note

There is a single signal controlling all the cells. So they will all capture or update their associated value at the same time.

The final component of boundary scan is to connect all the scan cells together in a chain, so that each cell can transfer its value to the adjacent cell. This is shown in Figure 2.4.




Figure 2.4. Boundary scan example: scan cells connected

The connected cells form a large shift register, with one bit for each input and output. The cells may be directed to *shift* their value to the adjacent cell. A sequence of shifts allows all the cells to be changed and all their values to be read out.

In the example shown, the cells form a 12-bit shift register, as shown in Figure 2.5.

$$\text{Bits shifted in} \rightarrow \boxed{A_3, A_2, A_1, A_4, A_5, A_6, B_3, B_2, B_1, B_4, B_5, B_6} \rightarrow \text{Bits shifted out}$$

Figure 2.5. Boundary scan example: shift register

A sequence of *capture*, followed by twelve *shifts* and then *update* allows the current state of each input to be recorded externally, a new set of values to be set and then injected onto the connections. In this way each input can be tested to check that when it is changed, its connected output changes.

2.1.2. JTAG Chip Architecture

IEEE 1149.1 describes a simple architecture for chips implementing boundary scan testing. In its minimal configuration, it provides four external pins, a clock (**TCK**), data in (**TDI**), data out (**TDO**) and a management signal (**TMS**). Collectively these pins are known as the *Test Access Port* (TAP).

Internally there are two registers in addition to the boundary scan register: the instruction register and the bypass register. Figure 2.6 shows this minimal architecture.




Figure 2.6. JTAG minimal architecture

Bits are shifted in on the positive edge of **TCK** and shifted out on the negative edge. The **TMS** signal is used to control the register into which the bits are shifted (instruction register, bypass register or boundary scan register). **TMS** usage is described more fully below.

The basic cycle of operation is a sequence of *capture* a register, *shift* in a new value from **TDI**, while simultaneously shifting out the old value on **TDO**, then *update* the register with the value shifted in.

The TAP controller can shift values either through the instruction register or through one of the other registers (collectively known as *data registers*). In the minimal configuration there are only two data registers: the boundary scan register and the *bypass register*. The bypass register is a convenient mechanism when boundary scan testing is not being used.

The *instruction register* must be at least 2 bits long. IEEE 1149.1 requires a minimum of 4 instructions:

- BYPASS** Capture, shift and update data through the bypass entry. This allows the chip to continue its normal operation. IEEE 1149.1 requires this instruction to consist of all 1's.
- SAMPLE** Capture and shift data through the boundary scan register, thus taking a sample of the data entering and leaving the chip via its inputs and outputs. However the update phase does not drive data onto inputs or outputs.
- PRELOAD** Shift data through the boundary scan register, thus setting up a value in the scan cells for future use. For this instruction, the capture phase does not get

the previous value into the cell and the update phase does not drive data onto inputs or outputs.

In early versions of the standard, this instruction was combined with **SAMPLE**.

EXTEST

The chip is placed in *extest mode* before data is captured, shifted and updated through the boundary scan register.

This is used to test connectivity between multiple chips. In *extest mode* the chip does not try to drive outputs or accept inputs. It is normal to use **PRELOAD** to set up the boundary scan register prior to **EXTEST**.

Early versions of IEEE 1149.1 required this instruction to consist of all 0's, although this is not the case in more recent versions.

TAP State Machine

The **TCK** and **TMS** signals drive a finite state machine in the TAP controller. **TMS** is sampled on the rising edge of **TCK** and used to advance the state. The state machine is shown in Figure 2.7.




Figure 2.7. TAP state machine

The actions taken in each state are as follows:

Test-Logic-Reset	In this state all test-modes (for example extest-mode) are reset, which will disable their operation, allowing the chip to follow its normal operation. At start-up the external logic will drive TMS high for at least 5 TCK cycles. This guarantees to reach the Test-Logic-Reset state and remain there.
Run-Test/Idle	This is the resting state during normal operation.
Select-DR-Scan Select-IR-Scan	These are the starting states respectively for accessing one of the data registers (the boundary-scan or bypass register in the minimal configuration) or the instruction register.

Capture-DR Capture-IR	These capture the current value of one of the data registers or the instruction register respectively into the scan cells. This is a slight misnomer for the instruction register, since it is usual to capture status information, rather than the actual instruction with Capture-IR.
Shift-DR Shift-IR	Shift a bit in from TDI (on the rising edge of TCK) and out onto TDO (on the falling edge of TCK) from the currently selected data or instruction register respectively.
Exit1-DR Exit1-IR	These are the exit states for the corresponding shift state. From here the state machine can either enter a pause state or enter the update state.
Pause-DR Pause-IR	Pause in shifting data into the data or instruction register. This allows for example test equipment supplying TDO to reload buffers etc.
Exit2-DR Exit2-IR	These are the exit states for the corresponding pause state. From here the state machine can either resume shifting or enter the update state.
Update-DR Update-IR	The value shifted into the scan cells during the previous states is driven into the chip (from inputs) or onto the interconnect (for outputs).

So we have a simple state machine, which allows either data registers or the instruction register to go through its capture-shift-update cycle, with an option to pause during the shifting.

Extending JTAG

IEEE 1149.1 specifies an optional asynchronous reset pin, **TRST**, an optional identification register and a number of optional instructions that may be included. The extended architecture is shown in Figure 2.8.




Figure 2.8. JTAG architecture with optional reset port and ID register

The reset pin, **TRST**, is active low. If driven low it immediately takes the state machine to the Test-Logic-Reset state.



Note

If **TRST** is not present, a synchronous reset can always be achieved by driving **TMS** high for 5 **TCK** cycles.

The *device identification register* is a 32-bit data register. It identifies version and part number for both manufacture and user. It can be read using the optional **ICODE** and **USERCODE** instructions.

Additional instructions also support **INTEST** (like **EXTEST**, but with on-chip test data), **RUNBIST** (to run comprehensive *Built-in Self Test* logic), **CLAMP** (to clamp outputs to predefined logic levels) and **HIGHZ** (to set all outputs to the disabled (high impedance) state).

Adding User Specific Registers to JTAG

JTAG provides a generic mechanism for accessing registers on chip. The standard allows the architecture to be extended with user registers, accessed using the user's own instructions. Figure 2.9 shows how these registers may be added.




Figure 2.9. JTAG architecture with user registers

The user will add their own instructions to access these additional registers. This is a common mechanism to interface to debug units on modern system-on-chip (SoC) designs.

2.2. OSCI SystemC IEEE 1666

The development of SystemC as a standard for modeling hardware started in 1996. Version 2.0 of the proposed standard was released by the Open SystemC Initiative (OSCI) in 2002. In 2006, SystemC became IEEE standard 1666-2005 [5].

Most software languages are not particularly suited to modeling hardware systems¹. SystemC was developed to provide features that facilitate hardware modeling, particularly the parallelism of hardware, in a mainstream programming language.

¹ There are some exceptions, most notably Simula67, one of the languages which inspired C++. In some respects it is remarkably like SystemC.

An important objective was that software engineers should be comfortable with using SystemC, even though it is a hardware modeling language. Rather than invent a new language, SystemC is based on the existing C++ language. SystemC is a true super-set of C++, so any C++ program is automatically a valid SystemC program.

SystemC uses the template, macro and library features of C++ to extend the language. The key features it provides are:

- A C++ class, **sc_module**, suitable for defining hardware modules containing parallel processes.



Note

Process is a general term in SystemC to describe the various ways of representing parallel flows of control. It has nothing to do with processes in the *Linux* or Microsoft Windows operating systems.

- A mechanism to define functions modeling the parallel threads of control within **sc_module** classes;
- Two classes, **sc_port** and **sc_export** to represent points of connection to and from a **sc_module**;
- A class, **sc_interface** to describe the software services required by a **sc_port** or provided by a **sc_export**;
- A class, **sc_prim_channel** to represent the channel connecting ports;
- A set of derived classes, of **sc_prim_channel**, **sc_interface**, **sc_port** and **sc_export** to represent and connect common channel types used in hardware design such as signals, buffers and FIFOs; and
- A comprehensive set of types to represent data in both 2-state and 4-state logic.

The full specification is 441 pages long [5]. The OSCI reference distribution includes a very useful introductory user guide and tutorial [7].

Chapter 3. Cycle Accurate SystemC JTAG Interface

This interface is designed for modeling environments which are both cycle accurate and pin accurate. In other words the state of each JTAG TAP port is accurately modeled on each bus cycle.

The objective is to provide a level of abstraction, so the user can concentrate on the modeling of register access through JTAG, rather than the minutiae of the TAP state machine and TAP signal states

3.1. Abstract Representation of the JTAG Interface

JTAG offers fundamentally two operations: scan bits through the instruction register or scan bits through a data register. The only other operation required is the ability to reset the TAP controller.

The SystemC interface reflects this, with classes representing a TAP instruction register scan (**TapActionScanIR**), a TAP data register scan (**TapActionScanDR**) and reset (**TapActionReset**).

The interface provides a SystemC module class representing the JTAG interface, **JtagSC**. The user can queue IR scan, DR scan and reset operations and **JtagSC** will generate the correct sequence of TAP pin outputs.

3.2. Application Programming Interface (API)

3.2.1. TAP Action Classes

TAP actions are represented by the abstract C++ class, **TapAction**. The three specific actions for reset, scan IR and scan DR are sub-classed from this. Figure 3.1 shows this relationship and summarizes the public interface as a class diagram.




Figure 3.1. Class diagram for JtagAction and subclasses

TapActionReset

This class represents a reset action for the TAP controller. There are no publicly accessible member variables of this class. The public methods are:

-

```
TapActionReset (sc_core::sc_event *_doneEvent)
```

The constructor for new TAP reset actions. It is passed a pointer to a SystemC event in **_doneEvent**, which will be notified when the action is complete.

TapActionIRScan

This class represents the action of scanning a value through the instruction register. There are no publicly accessible member variables of this class. The public methods are:

-

```
TapActionIRScan (sc_core::sc_event *_doneEvent,
                 uint32_t      _iRegIn,
                 int           _iRegSize)
```

The constructor for new TAP IR scan actions. It is passed a pointer to a SystemC event in **_doneEvent**, which will be notified when the action is complete.

The value to be scanned in (which will form the sequence of bits on **TDI**) is represented as a 32-bit integer in **iRegIn**. The actual number of bits to be scanned is an integer in **_iRegSize**.

32-bits seems a reasonable limit for the size of instruction register in any realistic JTAG architecture.

-

```
uint32_t getIRegOut ();
```

On completion of the action (as signaled through the SystemC event pointed to by **_doneEvent** this method will return the information that was scanned out of the instruction register. That is the sequence of bits that have appeared on **TDO**

As noted above, in the case of the instruction register this is not the actual value of the instruction, but some status bits about the interface.

TapActionDRScan

This class represents the action of scanning a value through a data register. This is more complex, because data registers are potentially very large—often larger than the 64-bits the largest integer that can be held in a single C++ variable.

To support this, values are represented as an array of 64-bit unsigned integers (**uint64_t**). However, for efficient handling of smaller data registers, variants are provided which represent the register in a single 64-bit **uint64_t**.

There are no publicly accessible member variables of this class. The public methods are:

-

```
TapActionDRScan (sc_core::sc_event *_doneEvent,
                 uint64_t      _dRegInArray[],
                 int           _dRegSize)
```

The constructor for new DR scan actions. It is passed a SystemC event in **_doneEvent**, which will be notified when the action is complete.

The value to be scanned in (which will form the sequence of bits on **TDI**) is represented as an array of 64-bit unsigned integers in **dRegInArray**. The actual number of bits to be scanned is an integer in **_dRegSize**.

This interface allows data registers of any size to be handled. However if this constructor is used for a small value it will automatically use the more efficient constructor described next.

-

```
TapActionDRScan (sc_core::sc_event *_doneEvent,
                 uint64_t      _dRegIn,
                 int           _dRegSize)
```

An alternative constructor for smaller registers (up to 64-bits). This is for use where the data to be scanned in is up to 64-bits long. It can be used for larger registers, so long as the actual value to be scanned in is only 64 bits or fewer.

The constructor is passed a SystemC event in **_doneEvent**, which will be notified when the action is complete.

The value to be scanned in (which will form the sequence of bits on **TDI**) is supplied as a 64-bit unsigned integer in **dRegIn**. The actual number of bits to be scanned is an integer in **_dRegSize**.

-

```
~TapActionDRScan ()
```

The destructor for DR scan actions. When handling more than 64 bits, arrays are allocated for internal data. If such arrays have been created, the destructor deletes them.

-

```
void getDRegOut (uint64_t dRegArray[])
```

On completion of the action (as signaled through the SystemC event pointed to by **_doneEvent** this method will return the information that was scanned out of the instruction register. That is, the sequence of bits that have appeared on **TDO**

The result is copied into the **uint64_t** array supplied in **dRegArray**. This interface can be used, even if this is a small register that can be held in a single variable. The result will be copied into **dRegArray[0]**.

-

```
uint64_t getDRegOut ();
```

On completion of the action (as signaled through the SystemC event pointed to by **_doneEvent** this method will return the information that was scanned out of the instruction register. That is, the sequence of bits that have appeared on **TDO**.

The value returned can be no larger than 64-bits. However this call may be used with a larger data register, in which case it will return the least significant 64 bits.

3.2.2. The JtagSC SystemC Module Class

This SystemC module class provides the primary interface. Users can queue instances of **TapAction** on its FIFO and it will generate the correct sequence of JTAG tap pin signals.

JtasSC defines a set of signal ports to connect to the target model implementing JTAG

-


```
sc_core::sc_in<bool> sysReset
```

Input. The system wide reset signal (active high). Whenever this is active **JtagSC** will drive the **TRST** signal to its active state (low).

- ```
sc_core::sc_in<bool> tck
```

*Input.* The JTAG clock signal. This must be synchronous with the **TCK** signals to connected devices implementing JTAG

- ```
sc_core::sc_out<bool> tdi
```

Output. The **TDI** signal. For **JtagSC** it is an *output*, because this class is generating the required signals on **TDI** from the actions which have been queued.

- ```
sc_core::sc_in<bool> tdo
```

*Input.* The **TDO** signal. For **JtagSC** it is an *output* from which the result of the actions which have been queued is built up

- ```
sc_core::sc_out<bool> tms
```

Output. The **TMS** signal. For **JtagSC** it is an *output*, because this class is generating the required signals to drive the TAP state machine from the actions which have been queued.

- ```
sc_core::sc_out<bool> trst
```

*Output.* The **TRST** signal. Driven low (active) whenever the system reset (**sysReset**) is active (high). For **JtagSC** it is an *output*, because this class generates the reset when required.

Users connecting to modules which do not implement **TRST** should tie this off to a dummy signal

**JtagSC** defines a FIFO on which users queue JTAG actions.

- ```
sc_core::sc_fifo<TapAction *> *tapActionQueue
```

The JTAG actions are of type **TapAction** and its subclasses. Over successive **TCK** cycles, the **JtagSC** will generate the required **TMS** and **TDI** signals and capture the **TDO** signals. When complete the SystemC **sc_event** from the action's creation is signaled.

The public methods of **JtagSC** are:

- ```
JtagSC (sc_core::sc_module_name name,
 int fifo_size = DEFAULT_TAP_FIFO_SIZE)
```

The constructor of new JTAG modules. The first argument, **name**, like all SystemC modules, is the name of the module. The optional second argument specifies the size of FIFO on which actions may be queued. Its default value, **DEFAULT\_TAP\_FIFO\_SIZE** is 256 in the current implementation.

- 

```
~JtagSC ()
```

The destructor for JTAG modules. This deletes the FIFO and a number of internal data structures.

### 3.2.3. Using the Interface

The user should instantiate an instance of **JtagSC** for each JTAG interface on the target model. The **JtagSC** ports should be connected to the system reset and TAP signal ports on the model using SystemC signals of type **sc\_signal<bool>**.

Other SystemC modules may then queue actions by writing instances of **TapActionReset**, **TapActionIRScan** and **TapActionDRScan** to the **JtagSC** FIFO. This is normally within the context of a **SC\_THREAD**, allowing the module to **wait** for notification when each action is complete.

## 3.3. Installation

The current implementation has been verified under Fedora 9 Linux using OSCI SystemC 2.2 and GCC 4.3.0. The author welcomes feedback about use under other operating systems.

- Unpack the source file, and change to the directory where the source is unpacked.

```
jxf embecosm-esp4-sysc-jtag-ca-1.0.tar.bz2
cd embecosm-esp4-sysc-jtag-ca-1.0
```

- Ensure the environment variable **SYSTEMC** is set to point to your SystemC distribution.
- Build the cycle accurate SystemC JTAG library.

```
make
```

- In the current implementation, there is no **make install**. Copy the resulting **libjtagsc.a** library and **jtagsc.h** header to the library and header directories of choice if desired.

To use the library, add the header directory to the GCC preprocessor flags and the library directory and library to the final linking command line. For example.

```
gcc -Iembecosm-esp4-sysc-jtag-ca-1.0 testprog.cpp
gdd -Lembecosm-esp4-sysc-jtag-ca-1.0 testprog.o -ljtagsc -o testprog
```

## 3.4. Implementation Detail

Each class described in the API is implemented as a header file defining the class and a code file with implementation of all the methods. So the class **JtagSC** is defined in **JtagSC.h** and implemented in **JtagSC.cpp**.

In addition to the classes described in Section 3.2, there is one more class, **TapStateMachine**, implementing the behavior of the TAP state machine.

The following sections provide brief notes on the implementation of each class.

### 3.4.1. JtagSC

In addition to the public instance variables which form part of the API, the main JTAG module maintains some private state.

- 

**TapStateMachine \*stateMachine**

This is an instance of the TAP state machine class (see Section 3.4.6), modeling the TAP state machine in the target to which this module is connected.

- 

**TapAction \*currentTapAction**

This is the JTAG action currently being processed through the TAP state machine. It has already been read from the FIFO.

### Constructor and Destructor Implementation

The constructor initializes the current TAP action (**currentTapAction**) to **NULL** and allocates new instances of the FIFO (**sc\_fifo**) and the TAP state machine (**TapStateMachine**).

It also declares the protected method **processActions** to be a SystemC method (**SC\_METHOD**), sensitive to the rising TCK (**tck.pos()**). It is this method that is responsible for progressing the queued actions on each clock cycle.

The destructor deletes the FIFO and TAP state machine to free the memory on completion.

### processActions

This function is declared in the constructor as a SystemC **SC\_METHOD**. It is invoked on every rising edge of TCK.

**TRST** takes its value as the inverse of the System reset (since it is active low, while the latter is active high). If the system is in reset, there is nothing else to do and the method returns.

If there is no TAP action currently being processed (i.e. **currentTapAction** is **NULL**) then the method attempts a non-blocking read from the FIFO.

If no new action is available from the FIFO, then **TMS** is driven to the appropriate state to move towards the Run-Test/Idle state and the method returns.

Having obtained (or already in progress of) a TAP action, its **process** method is invoked. This takes the current state machine and **TDO** and returns (via parameters) new values of **TDI** and **TMS**. It returns success if this completes the action.

In the event of successful completion, the SystemC event associated with the action is notified, and **currentTapAction** marked null, so a new action will be obtained from the FIFO on the next cycle.

The state machine is then advanced to its next state (based on the value of **TMS**), and the values of **TMS** and **TDI** used to drive the SystemC signals in **tdi\_o** and **tms\_o**.



#### Note

This function is only called on the positive edge of the clock, although **TDO** changes on the negative edge. However the value will still be there at the positive edge in all practical designs, so an additional call (with the associated computational overhead) is not required.

### 3.4.2. TapAction

This is the abstract base class of all the TAP action classes. It provides the common interface, expected by **JtagSC**.

**JtagSC** is declared a **friend** class and the pure virtual **process** method is made protected. This method can therefore be called by **JtagSC**, but not by other users of the class. Subclasses of **TapAction** are expected to implement this method.

Although there are no public instance variables which form part of the API, **TapAction** maintains some private state.

- 

```
sc_core::sc_event *doneEvent
```

The SystemC event which will be notified when an action completes.

- 

```
int resetCounter
```

A counter for use when resetting the TAP state machine of the target through **checkResetDone** (see below).

In addition to the pure virtual **process** method, **TapAction** provides the function **checkResetDone** (see below) as a utility for its subclasses.

#### checkResetDone

The **TapActionIRScan** and **TapActionDRScan** subclasses rely on the TAP state machine in **JtagSC** being an accurate reflection of the TAP state machine in the target. This can only be the case if both have been through a synchronous reset cycle (5 or more **TMS=1** cycles).

The **TRST** signal cannot be used as a guide, since it is an optional signal, which may not be implemented by targets.

Instead the TAP state machine class, **TapStateMachine** records whether it has been through a reset cycle. It relies on other classes to use (and set) this information as is helpful.

Both **TapActionIRScan** and **TapActionDRScan** check this information, and if necessary force the state machine through a reset to synchronize with the model.

This method is a utility to provide that function for subclasses. A subtlety of its implementation is that it sets the value of the TAP state machine flag as soon as it has provided the final (fifth) **TMS** signal, but does not return **true** to indicate no reset is needed until its subsequent call. This allows users to distinguish whether they are about to complete reset, or have already completed it in the previous **TCK** cycle. This in turn allows the method to provide the functionality for **TapActionReset**.

### 3.4.3. TapActionReset

This is the simplest of the **TapAction** subclasses, implementing a JTAG reset cycle. It has a sole private instance variable.

- 

```
bool firstTime
```

This is used to track the first call of the **process** method.

### Constructor

The constructor's key action is to set the **firstTime** instance variable to **true**.

### process

On the first cycle through, the TAP state machine's **resetDone** flag is cleared.

This allows the base class **checkResetDone** method to be used to drive the reset.

In this case completion is when the TAP state machine records the reset is done, not when the **checkResetDone** function returns **true**. This means completion is signaled on the final reset cycle, rather than after the final reset cycle. See Section 3.4.2 for the explanation of this behavior.

### 3.4.4. TapActionIRScan

This class implements capture, shift and update of a value through the instruction register. It has a number of private instance variables.

- 

```
uint32_t iRegIn
```

This is the value being shifted in through **TDI**. It holds the remaining bits to be shifted.

- 

```
int iRegSize
```

This is the number of bits to be shifted in through **TDI** and out through **TDO**

- 

```
uint32_t iRegOut
```

This is the value being shifted out through **TDO**. It holds the bits shifted out so far.

- 

```
int bitsShifted
```

The number of bits shifted in so far.

- 

```
enum {
 SHIFT_IR_PREPARING,
 SHIFT_IR_SHIFTING,
 SHIFT_IR_UPDATING
} iRScanState
```


This enumeration records where the action is in its process. The **process** method follows a state machine (see below) whose state is recorded here.

## Constructor

The primary responsibility of the constructor is to initialize all the instance variables. The input register and size are taken from the arguments, the output register and count of bits shifted are zeroed and the IR-Scan process state machine is set to **SHIFT\_IR\_PREPARING**.

## process

This method generates the appropriate values of **TDI** and **TMS** to process the action and capture **TDI**. It is controlled by its own state machine, whose state is recorded in **irScanState** as shown in Figure 3.2



**Figure 3.2. State machine for the JtagActionIRScan process.**

A subtlety of the implementation is that, because **TDO** changes on the *falling* edge, its value is always one step later than that of **TDI**. Thus **TDO** is not captured on the first cycle in Shift-IR state and its last bit is captured immediately after leaving Shift-IR state.

## getIRegOut

This function is part of the public API, allowing the user to access the value shifted through **TDO** on completion.

### 3.4.5. TapActionDRScan

This class implements capture, shift and update of a value through a data register. Functionally it is very similar to **TapActionIRScan**. However complexity is added, because data registers may be too large for a single C++ variable, so must be represented in arrays. **TapActionDRScan** has a number of private instance variables.

- 

```
int dRegBitSize
```

This is the number of bits to be shifted in through **TDI** and out through **TDO**.

- ```
int dRegWordSize
```

If **dRegBitSize** is more than 64, this is the number of elements in the **uint64_t** array used to represent the input and output registers, with the least significant bits in element 0.

- ```
uint64_t topMask
```

If register values are held in an array (i.e. **dRegBitSize** is more than 64), any odd number of bits (if **dRegBitSize** is not an exact multiple of 64) are held in the most significant element of the array. This is a mask for those bits.

- ```
uint64_t *dRegInArray
```

When the registers are held in an array (i.e. **dRegBitSize** is more than 64), this is a pointer to the array representing the value being shifted in through **TDI**. It holds the remaining bits to be shifted.

Since the original value is destroyed during processing, this is a copy of the array supplying the original value to the constructor.

- ```
uint64_t dRegIn
```

If the number of bits in a register (held in **dRegBitSize**) is 64 or less, the value to be shifted through **TDI** can be held in this simple variable for efficiency.

- ```
uint64_t *dRegOutArray
```

When the registers are held in an array (i.e. **dRegBitSize** is more than 64), this is a pointer to the array representing the value being shifted out through **TDO**. It holds the bits shifted out so far.

- ```
uint64_t dRegOut
```

If the number of bits in a register (held in **dRegBitSize**) is 64 or less, the value being shifted out through **TDO** can be held in this simple variable for efficiency.

- ```
int bitsShifted
```

The number of bits shifted in so far.

- ```
enum {
 SHIFT_DR_PREPARING,
 SHIFT_DR_SHIFTING,
 SHIFT_DR_UPDATING
} dRScanState
```

This enumeration records where the action is in its process. The **process** method follows a state machine (see below) whose state is recorded here.

### Constructors and destructor

As with the instruction register, the primary responsibility of the constructor is to initialize all the instance variables. The register size is taken from the arguments, the count of bits shifted is zeroed and the DR-Scan process state machine is set to **SHIFT\_DR\_PREPARING**.

There are two variants depending on whether the value to be shifted in through **TDO** is small enough to fit in a single 64-bit variable.

In either case, if the number of bits in the register size is greater than 64, the registers will be represented as an array of **uint64\_t**. Otherwise they will be represented as simple **uint64\_t** variables for efficiency.


Where registers are represented as vectors, new vectors of the correct size are allocated and the supplied input value copied to the input register. The output register is zeroed. The size of the vectors is recorded in **dRegWordSize**.

Otherwise the input value is copied to the local instance variable (**dRegIn**) and the output value (**dRegOut**) is zeroed.

The destructor is used to delete the local copies of registers where they have been represented as arrays to free the memory.

### process

As with **TapActionIRScan**, this method generates the appropriate values of **TDI** and **TMS** to process the action and capture **TDI**. It is controlled by its own state machine, whose state is recorded in **irScanState** as shown in Figure 3.3



**Figure 3.3. State machine for the JtagActionDRScan process.**



The operations on the registers vary depending on whether the register is more than 64 bits long. These operations (to shift bits out for **TDI** and in from **TDO**) are placed in separate utility functions, **shiftDRegOut** and **shiftDRegIn** (see below).

### **getDRegOut**

This function is part of the public API, allowing the user to access the value shifted through **TDO** on completion.

It is provided in two versions. In the first, the result is copied to an array of **uint64\_t** provided as an argument. This version may be used even if the register is 64 bits or smaller. The value will be copied into element 0 of the array.

The second version returns the value as a **uint64\_t**. This version may be used, even if the register is more than 64 bits long. The least significant 64 bits will be returned.

### **shiftDRegOut and shiftDRegIn**

These functions are used to shift the least significant bit out of **dRegInArray** (for use as **TDI**) and the shift in the most significant bit (from **TDO**) of **dRegOutArray**. However if the data register is represented as a scalar **uint64\_t** variable they will perform the equivalent operation on **DRegIn** and **DRegOut** instead.

## **3.4.6. TapStateMachine**

This class is for internal use by **JtagSC** and the various TAP action classes. It maintains the interface's model of the state machine in the TAP Controller.

The header defining this class also defines **enum TapState** for the various states of the TAP state machine.

**TapStateMachine** has a number of private instance variables.

- **TapState state**

The current state.

- **bool resetDone**

The TAP state machine is only of use if it correctly reflects the state machine in the TAP Controller of the target. This flag may be set and read by users to reflect whether the two are in synchrony (for example having gone through a sequence of 5 or more **TMS=1** transitions).

### **Constructor**

The constructor initializes the state to Test-Logic-Reset and clears the flag indicating the TAP controller has been reset. Until a reset has been completed, there can be no confidence that the state is a correct reflection of reality.

### **Accessor Functions**

The functions **getState** is provided to get the current state. The functions **getResetDone** and **setResetDone** are provided to access the flag indicating whether a reset has been completed. Although initialized to false, it is the responsibility of users to set this flag to its correct value.



#### **nextState**

This uses table lookup to advance the state, based on the supplied value of **TMS**.

#### **targetState**

This function returns through its second argument a value of **TMS** which will move from the current state to the specified target state most efficiently (i.e. smallest number of steps). Table lookup makes this an efficient function.

The return value indicates if the state machine was already in the target state.


This function is used by the instruction and data scan TAP action classes to get to the correct state during their **process** functions.

## Chapter 4. Examples

Both examples in this chapter use the OpenRISC Reference Platform System-on-Chip, *ORPSoC* ([6]). A cycle accurate SystemC model was generated automatically from the source using *Verilator* ([8]).

*ORPSoC* features a JTAG interface with a number of user register which drive its debug unit. These examples show the result of resetting the unit, writing a register less than 64-bits long and reading a register more than 64-bits long.

The SystemC model consists of four modules: the *ORPSoC* module created by *Verilator* (class **Vorpsoc**), a reset signal generator (class **ResetSC**), the JTAG module using the interface described in this application note (class **JtagSC**) and a simple driver module to inject JTAG requests (class **JtagDriver**). The module structure and their interconnects are shown in Figure 4.1.



**Figure 4.1. Module structure for the *ORPSoC* JTAG example**

The clock is provided by a **sc\_clock** and used to drive both the system clock of *ORPSoC* and the JTAG **TCK** signals. The reset generator, **ResetSC** generates a reset signal for a predefined number of clock cycles after time zero. The two outputs offer active high (**rst**) and active low (**rstn**) versions, synchronous with each other.

### 4.1. JTAG Reset

The code to drive reset of the JTAG is as follows.

```

sc_core::sc_event *actionDone = new sc_core::sc_event();
TapActionReset *resetAction;


resetAction = new TapActionReset (actionDone);
tapActionQueue->write (resetAction);
wait (*actionDone);

delete resetAction;
delete actionDone;

```

A new instance of **TapActionReset**, **resetAction** is created using the SystemC event, **actionDone**. This action is queued by writing to the FIFO (**tapActionQueue**, waiting for the result on **actionDone**).

With the results traced in a VCD the effect can be seen clearly. The trace is shown in Figure 4.2.



**Figure 4.2. VCD trace of a JTAG reset request**

During system reset, the JTAG TRST is driven low. As soon as the system reset is complete at 1µs, the JTAG reset can be processed. A sequence of 5 cycles of TMS=1 is seen from 1µs onwards.



**Note**

The VCD trace shows the signals changing on the falling edge of the clock. This is a cycle accurate model, with values only sampled on clock edges. The JTAG signals change in response to the stimulus from the clock, so only appear in the trace at the next clock edge. This is a common effect in cycle accurate modeling, but does not affect the behavior of the model.

## 4.2. Writing the Instruction Register

The ORPSoC JTAG interface uses a 4-bit instruction register with a number of custom instructions. One such instruction **CHAIN** is used to select the custom CHAIN register. This instruction has the binary value 0011.

The code to write the **CHAIN** instruction into the instruction register is:

```

sc_core::sc_event *actionDone = new sc_core::sc_event();
TapActionIRScan *iRScan;

iRScan = new TapActionIRScan (actionDone, CHAIN_SELECT_IR, JTAG_IR_LEN);
tapActionQueue->write (iRScan);
wait (*actionDone);

delete iRScan;

```


The action is created as a new instance of `TapActionIRScan`, passing in a SystemC event for signaling completion, with the value of the instruction (`CHAIN_SELECT_IR`, binary 0011) and the instruction register length (`JTAG_IR_LEN`, 4 in the case of ORPSoC).



#### Note

In this case the SystemC event, `actionDone` is not deleted. It will be reused for the following data register write action (see Section 4.3).

The results are again traced in a VCD and shown in Figure 4.3.



**Figure 4.3. VCD trace of a JTAG instruction register write request**

The instruction register write action commences at  $1.6\mu\text{s}$ . A sequence of 0-1-1-0-0 on `TMS` takes the state machine from its starting point of Test-Logic-Reset through Run-Test/Idle, Select-DR-Scan, Select-IR-Scan and Capture-IR to Shift-IR.

At this point a sequence of four `TMS=0`, starting at  $2.0\mu\text{s}$  allow the bits of the instruction register to be shifted in from `TDI`. The sequence 1-1-0-0 can be seen on `jtag_tdi`. Since the bits are shifted in least-significant bit first, this represents the binary number 0011, the `CHAIN` instruction.

A sequence of 1-1 on `TMS` moves the state machine through Exit1-IR to Update-IR at which point completion is signaled ( $2.5\mu\text{s}$ ).

### 4.3. Writing a 12-bit JTAG Data Register

The `ORPSoC` JTAG `CHAIN` instruction selects the debug unit's 12-bit `CHAIN` register as the data register to be written.

The code to write the data into the `CHAIN` data register is:

```
uint64_t dReg = 0x4;
dReg |= crc8 (chain, 4) << 4;
```

```


dRScan = new TapActionDRScan (actionDone, dReg, 12);
tapActionQueue->write (dRScan);
wait (*actionDone);

delete dRScan;
delete actionDone;

```

The 12-bit data is built up in **dReg** from a value (bits 0-3) and a CRC (bits 4-11). The action is created as a new instance of **TapActionDRScan**, passing in a SystemC event for signaling completion (reusing the signal from the instruction register write earlier), with the data value and the data register length. In this example the 12-bit value is 0000\_1110\_0100.

The results are again traced in a VCD and shown in Figure 4.4.



**Figure 4.4. VCD trace of a "small" JTAG data register write request**

The data register write action commences at 2.6µs. The TAP state machine is currently at Update-IR from the previous write of an instruction register. A **TMS** sequence of 1-0-0 takes the state through Select-DR-Scan and Capture-DR to Shift-DR. 12 cycles in Shift-DR (the last with **TMS**=1 to move out of Shift-DR) starting at 2.9µs shift in the sequence 0-0-1-0-0-1-1-1-0-0-0-0 on **TDI**, the value specified, least significant bit first. The final **TMS**=1 moves the state to Exit1-DR, followed by another **TMS**=1 to move to Update-DR. Completion can be signaled at this point, at time 4.1µs.

In this example the bits being shifted out on **TDO** can also be seen. The *ORPSoC* debug unit always shifts out the CRC as the last 8-bits, and the sequence 0-1-1-1-0-0-0-0 can be seen as the final bits on **TDO**, which is the original 8-bit CRC (00001110) in least significant bit first.

Note how the bits are delayed half a cycle from the **TDI** bits, because **TDO** changes on the falling edge of **TCK** (and on this cycle accurate trace will be shown on the following rising edge). Thus the final bit is picked up as the Exit1-DR state is entered.

#### 4.4. Reading a 73-bit JTAG Data Register

This final example shows the JTAG interface's facilities for handling large data registers. This example shows a read from one of the *ORPSoC* JTAG 73-bit debug registers

The code to read a register also involves scanning in data, and for *ORPSoC* that data must have a correct CRC to be accepted. The code is as follows:

```

sc_core::sc_event *actionDone = new sc_core::sc_event();
uint64_t dRegArray[2];
memset (dRegArray, 0, 16);
dRegArray[0] |= data;
uint8_t crc_in = crc8 (dRegArray, 65);
insertBits (crc_in, 8, dRegArray, 65);

TapActionDRScan *dRScan = new TapActionDRScan (actionDone, dRegArray, 73);
tapActionQueue->write (dRScan);
wait (*actionDone);


dRScan->getDRegOut (dRegArray);
delete dRScan;
delete actionDone;

```

The 73-bit data is built up in the array **dRegArray** from a value (bits 0-64) and a CRC (bits 65-72). The action is created as a new instance of **TapActionDRScan**, passing in a SystemC event for signaling completion, with the data value array and the data register length.

After completion, the result is retrieved back into **dRegArray** using the **getDRegOut** method of the **TapActionDRScan** class.

The results are again traced in a VCD and shown in Figure 4.5.



**Figure 4.5. VCD trace of a "large" JTAG data register read request**



The data register read action commences at 23.4 $\mu$ s. The TAP state machine is currently at Update-IR from the previous write of an instruction register. A **TMS** sequence of 1-0-0 takes the state through Select-DR-Scan and Capture-DR to Shift-DR. There are then 73 cycles in Shift-DR (the last with **TMS**=1 to move out of Shift-DR) starting at 23.7 $\mu$ s. The value is shifted out least significant bit first on **TDO** (one cycle delayed, since it is on the negative edge). The value is 0x062000000020000000.

The final **TMS**=1 moves the state to Exit1-DR, followed by another **TMS**=1 to move to Update-DR. Completion can be signaled at this point, at time 31.1 $\mu$ s.





## Chapter 5. Summary

This application note presents a SystemC interface suitable for cycle accurate modeling of JTAG. It will be of value to engineers developing cycle accurate models, who need to interface to other modules, to develop test benches, or to connect to tools such as debuggers.

Suggestions for corrections or improvements are welcomed. Please contact the author at [jeremy.bennett@embecosm.com](mailto:jeremy.bennett@embecosm.com).

## Glossary

### 2-state

Hardware logic model which is based only on logic high and logic low (binary 0 and binary 1) values.

See also: 4-state.

### 4-state

Hardware logic model which considers unknown (**X**) and unproven (**Z**) values as well as logic high and logic low (binary 0 and binary 1).

See also: 2-state.

### big endian

A description of the relationship between byte and word addressing on a computer architecture. In a big endian architecture, the least significant byte in a data word resides at the highest byte address (of the bytes in the word) in memory.

The alternative is little endian addressing.

See also: little endian.

### Joint Test Action Group (JTAG)

JTAG is the usual name used for the IEEE 1149.1 standard entitled *Standard Test Access Port and Boundary-Scan Architecture* for test access ports used for testing printed circuit boards and chips using boundary scan.

This standard allows external reading of state within the board or chip. It is thus a natural mechanism for debuggers to connect to embedded systems.

### little endian

A description of the relationship between byte and word addressing on a computer architecture. In a little endian architecture, the least significant byte in a data word resides at the lowest byte address (of the bytes in the word) in memory.

The alternative is big endian addressing.

See also: big endian.

### Open SystemC Initiative (OSCI)

The industry standardization body for SystemC/

### System on Chip (SoC)

A silicon chip which includes one or more processor cores.

### SystemC

A set of libraries and macros, which extend the C++ programming language to facilitate modeling of hardware.

Standardized by the *Open SystemC Initiative*, who provide an open source reference implementation.

See also: Open SystemC Initiative.



Test Access Port (TAP)

The interface to a JTAG interface defined by IEEE 1149.1.

## References

- [1] Doxygen: Source code documentation generator tool, Dimitri van Heesch, 2008 . <http://www.doxygen.org>
- [2] Embecosm Software Package 4. Cycle Accurate SystemC JTAG Interface: Reference Implementation. Embecosm Limited, January 2009. Available for free download from the Embecosm website at [www.embecosm.com](http://www.embecosm.com) .
- [3] IEEE standard test access port and boundary-scan architecture IEEE Computer Society 2001 (reaffirmed 2008) . IEEE Std 1149.1™-2001 .
- [4] IEEE Std 1149.1 (JTAG) Testability: Primer. Texas Instruments Semiconductor Group 1997. Available for free download from the Texas Instruments website at [focus.ti.com/lit/an/ssya002d/ssya002d.pdf](http://focus.ti.com/lit/an/ssya002d/ssya002d.pdf) .
- [5] IEEE Standard SystemC® Language: Reference Manual. IEEE Computer Society 2005 . IEEE Std 1666™-2005. Available for free download from [standards.ieee.org/getieee/1666/index.html](http://standards.ieee.org/getieee/1666/index.html) .
- [6] The OpenRISC Reference Platform System-on-Chip ORSoC AB (through the OpenCores website) [www.opencores.org](http://www.opencores.org)
- [7] SystemC Version 2.0 User Guide. Open SystemC Initiative, 2002.
- [8] Verilator 3.700. Wilson Snyder, January 2009. Veripool, [www.veripool.org/wiki/verilator](http://www.veripool.org/wiki/verilator)